


**DC-00TX(QC) Series**

**Wired Transmitter for Preset Torque Wrench**



Note: DC-00TX model is a wired transmitter, the torque wrench is not included in this model.

- This wired transmitter unit may be preferred where interference may interfere with the wireless signal transmission.
- Wired transmitter unit mounted at the end of the torque wrench. Each time the torque wrench "clicks", an ok signal is sent to the external receiver for further processing of the signal information.
- Power supply should be DC24/2A. Make sure the torque wrench is in good condition and connect the aviation plug with wire to start using.



Note: The wired transmitter can be used with most NovaTork preset torque wrench of PC / PCH series. If you need it, please consult the supplier.