



Note: Torque Tester and Torque Wrench are not included in TS model.

TS Series Manual Loader for Torque Wrench Testing

- Large diameter wheel for easy and smooth application of torque.
- Different load cells may be used, some requiring special mounting adapters.
- Instrument rack tray is adjustable for comfort and good visibility.
- Can be adjusted to accommodate different wrench lengths and heights.
- Torque Tester and Torque Wrench are not included.

Item No.	Max.Torque N.m	Arm Length		Length mm	Width mm	Height mm	Weight kg
		Min(mm)	Max(mm)				
TS1350	350	197	686	860	290	590	32.5
TS11100	1100	380	1350	1760	350	590	76
TS12000	2000	420	1690	2090	350	590	80

Customized for special requirements.



*Matching TEM torque tester,
please check TEM model for details*